



Bleaching (Colour change)

Description

Discolored patches in topcoat corresponding to areas of polyester putty in the substrate.

Cause

- Excess quantities of peroxide hardener used in the putty;

Prevention

- Use recommended quantity of hardener;
- Calculate and measure hardener accurately;
- Use a feed machine for mixing;
- Mix thoroughly;

Rectification

- Sand the affected area to the surface of the putty, isolate with filler or epoxy primer and repaint.